Lube Control Pty Ltd

HOW TO EXTEND A PUMP TUBE



EXTENSION TUBE ASSEMBLY



NOTE

Ensure A B attach to the end of suction tube